

Standard and optional equipment
 Standard: ■
 Optional: □

FENDT 200 V/F/P VARIO

Equipment variants.*



	200 V Power	200 V Profi	200 V Profi+	200 F Power	200 F Profi	200 F Profi+	200 P Power	200 P Profi	200 P Profi+
Engine									
Reversible fan	□	□	□	□	□	□	□	□	□
Engine pre-heating	□	□	□	□	□	□	□	□	□
Transmission									
Vario TMS - Tractor Management System	■	■	■	■	■	■	■	■	■
Shuttle function, stop-and-go function	■	■	■	■	■	■	■	■	■
Cruise control	■	■	■	■	■	■	■	■	■
Guidance system									
Guidance system basic package			■			■			■
Standard Trimble / NovAtel			□			□			□
RTK Trimble / NovAtel			□			□			□
TI Auto			□			□			□
Contour Assistant			□			□			□
Agronomy									
Agronomy basic package			□			□			□
Telemetry									
Telemetry basic package			□			□			□
Machine control									
ISOBUS 200 machine control (in-cab)		□	□		□	□		□	□
Section Control (SC)			□			□			□
Variable Rate Control (VRC)			□			□			□
Vario operation									
Multi-function joystick with cruise control, engine speed memory, automatic modes, controls for hydraulics	■	■	■	■	■	■	■	■	■
3L joystick		□	□		□	□		□	□
Individual Operation Manager – flexible key assignment	■	■	■	■	■	■	■	■	■
Digital Dashboard	■	■	■	■	■	■	■	■	■
12" terminal with touchscreen and key control		□	■		□	■		□	■
Fendt Active steering		□	■		□	■		□	■
Cab									
Comfort cab	■	■	■	■	■	■	■	■	■
Category 4 cab air filter system		□	□		□	□		□	□
Comfort seat, air sprung	■	■	■	■	■	■	■	■	■
Height and tilt-adjustable steering column	■	■	■	■	■	■	■	■	■
Air-conditioning	■	■	■	■	■	■	■	■	■
Integrated automatic climate control	□	□	□	□	□	□	□	□	□
One-piece windscreen and door on right	■	■	■	■	■	■	■	■	■
Rear window wash/wipe	□	□	□	□	□	□	□	□	□
Telescoping rear view mirror	□	□	□	□	□	□	□	□	□
Auxiliary device holder	□	□	□	□	□	□	□	□	□
4 camera connections (digital/analogue)		□	□		□	□		□	□
Fendt Reaction steering system	■	■	■	■	■	■	■	■	■
Self-cancelling indicators	■	■	■	■	■	■	■	■	■
Brake level device	□	□	□	□	□	□	□	□	□
Electric battery disconnect switch	□	□	□	□	□	□	□	□	□
Lighting									
Bi-halogen headlights	■	■	■	■	■	■	■	■	■
Auxiliary lights front	□	□	□	□	□	□	□	□	□
A-pillar LED work lights	□	□	□	□	□	□	□	□	□
Roof rear LED work lights	□	□	□	□	□	□	□	□	□
Front roof work lights	□	□	□	□	□	□	□	□	□
Roof front LED work lights	□	□	□	□	□	□	□	□	□
LED rear lights	■	■	■	■	■	■	■	■	■
Daylight running light	□	■	■	□	■	■	□	■	■
LED rotating beacons	□	□	□	□	□	□	□	□	□

	200 V Power	200 V Profi	200 V Profi+	200 F Power	200 F Profi	200 F Profi+	200 P Power	200 P Profi	200 P Profi+
Chassis									
Front axle suspension self-levelling, anti-roll control, lockable	□	□	□	□	□	□	□	□	□
Compressed air system 2-circuit system	□	□	□	□	□	□	□	□	□
4WD / differential locks									
Automatic all-wheel drive and differential locking with steering angle sensors	■	■	■	■	■	■	■	■	■
Automatic front differential lock							■	■	■
Rear / front differential with 100% disc locking and steering angle sensors	■	■	■	■	■	■			
Power lift									
Sa front power lift, with external control (separate valve)	□	□	□	□	□	□	□	□	□
Single-action Comfort front power lift with position adjustment and external controls							□	□	□
Dual-action comfort front power lift with position control and relief control, external controls							□	□	□
Externally controlled rear power lift	■	■	■	■	■	■	■	■	■
Shock load stabilising, electro-hydraulic power lift control	■	■	■	■	■	■	■	■	■
Swinging power lift	■	■	■	■	■	■			
Hydr. lateral and tilt adjustment with enhanced actuation	□	□	□	□	□	□			
Rear power lift relief control		□	□		□	□			
Steep lift	□	□	□	□	□	□	□	□	□
PTO									
Front: 540E rpm	□	□	□	□	□	□	□	□	□
Front: 1000 rpm	□	□	□	□	□	□	□	□	□
Rear PTO 540/WZW/750 rpm	□	□	□	□	□	□	□	□	□
Rear PTO 540/540E/1000 rpm	■	■	■	■	■	■	■	■	■
External controls for rear PTO	■	■	■	■	■	■	■	■	■
Hydraulics									
EHS valve actuation crossgate lever, multi-function joystick	■	■	■	■	■	■	■	■	■
EHS valve actuation linear module		■	■		■	■		■	■
Hydraulic tandem pump, hydraulic oil cooler (42+ 33 l/min)	■			■			■		
Load sensing system with axial piston pump (48+71 l/min)	□	■	■	□	■	■	□	■	■
1st EHS valve middle and rear	■	■	■	■	■	■	■	■	■
3rd EHS valve middle and rear	□	□	■	□	□	■	□	□	■
4th EHS valve middle and rear	□	□	□	□	□	□	□	□	□
1st hydraulic valve centre left/rear		□	□		□	□		□	□
2nd hydraulic valve centre left		□	□		□	□		□	□
7th and 8th EHS valve centre left		□	□		□	□		□	□
Hydraulic power beyond connection		□	□		□	□		□	□
Return middle right	■	■	■	■	■	■	■	■	■
Return rear	■	■	■	■	■	■	■	■	■
CUP coupling rear	□	□	□	□	□	□	□	□	□
Bio hydraulic oil	□	□	□	□	□	□	□	□	□
Additional equipment									
Manual hitch	■	■	■	■	■	■	■	■	■
Automatic trailer hitch without remote control, rear	□	□	□	□	□	□	□	□	□
Front weights, various sizes	□	□	□	□	□	□	□	□	□
Wheel weights, rear wheels	□	□	□	□	□	□	□	□	□
Implement mounting plate	□	□	□	□	□	□	□	□	□

* Please refer to the Settings for equipment variants

